


GORILLA TOWER MOUNT- DECK INSTALLATION INSTRUCTIONS

PARTS LIST:

1. Gorilla Tower Mount, and Post Skirt
2. ½"-13 x 12" zinc plated threaded rod, 1 per pack
3. 3" x 3" galvanized steel plate, 2 per pack
4. ½"-13 zinc plated hex nut, 2 per pack
5. ½" zinc plated lock washer, 2 per pack
6. ½" USS zinc plated flat washer, 2 per pack
7. #6 x 1 ½" pan or flat, Phillips or square, type A stainless screws, 8 per pack
8. Plastic Leveling Wedges, 2 per pack

INSTALLATION:

1. Locate center of post position on decking surface and mark with a pencil. Drill a ⅝" hole through the deck and substructure. The substructure can be a 2" x 6" cross brace secured between the joists.
2. Insert the threaded rod through the Mount and place over the drilled hole. Level the Mount with the supplied wedges. Place the 3" x 3" steel plate over the rod. Next place the flat washer, the lock washer and nut on the threaded rod. Repeat this process under the deck. Tighten the Mount using box wrenches on the nuts until the lock washers are fully compressed.
3. Place the 4" x 4" post over the mount and seat the post into the recess. Secure all four sides of the post with the self tapping screws through the post and into the Tower Mount, using two on each side. Slip the skirt over the post to cover the screws and snap into place.



GORILLA TOWER MOUNT- CONCRETE INSTALLATION INSTRUCTIONS – 4” SLAB OR GREATER

PARTS LIST:

1. Gorilla Tower Mount and Post Skirt
2. ½”-13 x 12” zinc plated threaded rod, 1 per pack
3. 3” x 3” galvanized steel plate, 1 per pack
4. 1- adhesive capsule
5. ½”-13 zinc plated hex nut, 1 per pack
6. ½” zinc plated lock washer, 1 per pack
7. ½” USS zinc plated flat washer, 1 per pack
8. #6 x 1 ½” pan or flat, Phillips or square, type A stainless screws, 8 per pack
9. Plastic Leveling Wedges, 2 per pack

INSTALLATION:

1. Locate center of post position on concrete surface and mark with a pencil. Drill a 5/8” hole in the concrete at a minimum of 3 ½” depth.
2. Clean the hole with compressed air. Insert the adhesive capsule with the round side up in the hole. Place the threaded rod on the top of the capsule. Hammer the threaded rod through the adhesive capsule. Clean any excess adhesive off of the concrete surface. Allow 1/2 hour to cure at 70° F. If between 32° F and 70° F allow 1 hour to cure.
3. Place the Tower Mount over the threaded rod. Level the Mount with the supplied wedges. Place the 3” x 3” steel plate over the rod. Next place the flat washer, the lock washer and nut on the threaded rod. Tighten the Mount using a box wrench on the nut until the lock washer is fully compressed.
4. Place the 4” x 4” post over the mount and seat the post into the recess. Secure all four sides of the post with the self tapping screws through the post and into the Tower Mount, using two on each side. Slip the skirt over the post to cover the screws and snap into place.

